

REPLACEMENT PARTS GUIDE

3033R Compact Utility Tractor (1LV3033RAHJ100001-) (Worldwide Edition)

ENGINE



ENGINE OIL
[TY26668](#) (10W-30 PLUS-50™ II) (5.4 L (1.4 gal))

Change Every 200 Hrs or Annually, whichever comes first.



FUEL FILTER
[MIU803127](#) (HH100001 -)

Change after every 400 Hrs/Annually.



AIR FILTER
[RE68048](#) (PRIMARY)
[RE68049](#) (SECONDARY)

Change every 600 hrs. or annually.



JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE
[TY6341](#)
GREASE GUN
[TY26183](#)

Change As Required.



OIL FILTER
[M806419](#)

Change Every 200 Hrs or Annually, whichever comes first.



FUEL-WATER SEPARATOR
[MIU803221](#) (SEPARATOR)
[MIU802421](#) (FILTER ELEMENT)

Change after every 400 Hrs. or annually.



DIESEL PARTICULATE FILTER
[MIU803093](#)



HOME MAINTENANCE KIT
[LVA21038](#)

AXLE



TIE ROD
[LVA19527](#) (ASSEMBLY)
[LVA14960](#) (LH)
[LVA14959](#) (RH)



FRONT AXLE OIL
[TY22000](#) (John Deere Low Viscosity Hy-Gard™)

Change every 50/400/600 Hrs.

ELECTRICAL



KEY
[RE183935](#)



ROTARY SWITCH
[LVA21501](#)



BATTERY
[TY27831B](#) (12 V)



LED WORK LIGHT, OOS
[AM143579](#) (12 V)



HEADLIGHT
[R136239](#) (12 V 60/55 W)

FUEL & AIR



FILLER CAP
[AL213202](#)

CAB



CAB FILTER
[MIU10010](#)
 Clean or replace after every 50 hours and as required.



RECIRCULATION AIR FILTER
[MIU10011](#)
 Clean or replace after every 50 hours and as required.

TRANSMISSION/ HYDRAULIC



TRANSMISSION/HYDRAULIC OIL
[TY22000](#) (47.3 L (12.5 gal.))
 Change after every 400 Hrs. or annually.



OIL FILTER
[LVA13065](#) (TRANSMISSION) (HH100001 -)
[LVA12678](#) (HYDRAULIC)
 Change after every 400 Hrs. or Annually.



V - BELT
[LUVU29376](#) (LGTH = 1112 mm, WIDTH = 13.4 mm, TK = 9.6 mm)

