

# REPLACEMENT PARTS GUIDE

## 325G (PIN: 1T0325G\_\_\_G328658—)



### ENGINE AIR FILTER ELEMENT—PRIMARY

[AT338105](#)

Interval (hrs) - As required.



### ENGINE AIR FILTER ELEMENT—SECONDARY

[AT336803](#)

Interval (hrs) - As required.



### HYDRAULIC OIL FILTER

[AT435649](#)

Interval (hrs) - 500.



### CAB FRESH AIR FILTER ELEMENT (IF EQUIPPED)

[AT441536](#)

Interval (hrs) - As required.



### CAB RECIRCULATION AIR FILTER ELEMENT (IF EQUIPPED)

[AT359416](#)

Interval (hrs) - As required.



### FUEL TANK BREATHER

[H216169](#)

Interval (hrs) - 1000.

1

2

3

4

5

6



7

8

9

10

11

12



### ENGINE OIL FILTER

[MIU800650](#)

Interval (hrs) - 500



### Final Fuel Filter

[MIU801090](#)

Interval (hrs) - 500



### Primary Fuel Filter and Water Separator

[MIU801025](#)

Interval (hrs) - 500



### ENGINE ROCKER ARM COVER GASKET

[MIU801150](#)

Interval (hrs) - 1500



### HYDRAULIC OIL RESERVOIR BREATHER

[AT101565](#)

Interval (hrs) - 1000.



### DUST UNLOADER VALVE

[M89679](#)

Interval (hrs) - As required.







**JOHN DEERE**  
Genuine Parts and Service

CLICK PART NUMBER TO BUY

\*See operator's manual for additional details.

# REPLACEMENT PARTS GUIDE

325G (PIN: 1T0325G\_\_G328658— )

Part Description	Qty or capacity	Change Interval In Hours
John Deere Plus-50™ II Engine Oil <sup>2</sup> 	12.5 L (3.3 gal)	500
John Deere Hydrau™ Hydraulic and Hydrostatic Oil <sup>2</sup> 	26.5 L (7.0 gal)	1000
API G1-5 Final Drive Planetary Oil <sup>2</sup> (per side) (325G only) 	0.8 L (27.0 oz)	1000
John Deere Cool-Gard™ II Pre-Mix 	12.5 L (3.3 gal)	6000
Fluid Analysis Kits <sup>3</sup>		
Diesel Engine Oil	1	500
Hydraulic Oil	1	500
Hydrostatic Planetary Gear Case Oil (325G only)	2	500
Diesel Fuel	2	500
Engine Coolant	1	500
<sup>2</sup> See operator's manual for recommended oil type and oil viscosities based on operating temperatures. <sup>3</sup> Based on fluid analysis results, intervals may need to be adjusted for operating conditions. Consult an authorized John Deere dealer.		

Plus-50 is a trademark of Deere & Company

Hy-Gard is a trademark of Deere & Company

Hydrau is a trademark of Deere & Company

COOL-GARD is a trademark of Deere & Company

## Service Intervals

325G (PIN: 1T0325G__G328658— )	
<b>As Required</b>	
<input type="checkbox"/> Check accessory drive belt	<input type="checkbox"/> Check fuel tank breather
<input type="checkbox"/> Replace cab fresh air filter (if equipped)	<input type="checkbox"/> Drain water and sediment from fuel tank
<input type="checkbox"/> Replace cab recirculation air filter (if equipped)	<input type="checkbox"/> Check and drain primary fuel filter and water separator
<input type="checkbox"/> Replace primary engine air filter element	<input type="checkbox"/> Check and adjust steering mistracking
<input type="checkbox"/> Replace secondary engine air filter element (every 3rd primary element replacement or as required)	<input type="checkbox"/> Check tire pressure (320G and 324G)
<input type="checkbox"/> Check and clean cooling package	<input type="checkbox"/> Check wheel lug nut torque (320G and 324G)
<b>Every 10 Hours or Daily</b>	
<input type="checkbox"/> Check coolant level	<input type="checkbox"/> Check hydraulic oil level
<input type="checkbox"/> Check engine oil level	<input type="checkbox"/> Lubricate boom linkage, cylinder pivot points, and Quik-Tatch™ linkage
<b>Initial Service—50 Hours<sup>1</sup></b>	
<input type="checkbox"/> Drain and refill hydrostatic planetary gear case oil (325G only)	
<b>Every 50 Hours</b>	
<input type="checkbox"/> Check and clean dust unloader valve	<input type="checkbox"/> Check track tension (325G only)
<b>Every 250 Hours</b>	
<input type="checkbox"/> Take engine oil sample	
<b>Every 500 Hours</b>	
<input type="checkbox"/> Drain and refill engine oil and replace oil filter	<input type="checkbox"/> Take hydrostatic planetary gear case oil sample (325G only)
<input type="checkbox"/> Replace primary fuel filter and water separator	<input type="checkbox"/> Take hydraulic oil sample
<input type="checkbox"/> Replace final fuel filter	<input type="checkbox"/> Take diesel fuel sample
<input type="checkbox"/> Replace hydraulic oil filter	<input type="checkbox"/> Take engine coolant sample
<input type="checkbox"/> Lubricate steering linkage (if equipped)	<input type="checkbox"/> Check chain case oil level (320G and 324G)
<b>Every 1000 Hours</b>	
<input type="checkbox"/> Drain and refill hydraulic oil	<input type="checkbox"/> Replace fuel tank breather
<input type="checkbox"/> Drain and refill hydrostatic planetary gear case oil (325G only)	<input type="checkbox"/> Check coolant condition
<input type="checkbox"/> Replace hydraulic oil reservoir breather	<input type="checkbox"/> Drain and refill chain case oil (320G and 324G)
<b>Every 1500 Hours</b>	
<input type="checkbox"/> Check and adjust engine valve lash	
<b>Every 6000 Hours</b>	
<input type="checkbox"/> Drain and refill cooling system	