

REPLACEMENT PARTS GUIDE

9R Interim Tier 4 (IT4) Series Wheel Tractors(000101-014999) – 9360R, 9410R, 9460R, 9510R and 9560R FILTER OVERVIEW WITH SERVICE INTERVALS

ENGINE



DIESEL PARTICULATE FILTER (DPF)

[RE542183](#) (9360R)
[RE541836](#) (9410R, 9460R, 9510R, 9560R)

Replace within 250 hours after warning light indicators are illuminated. See your John Deere™ dealer or qualified service provider.



PRIMARY AIR FILTER

[RE312946](#)



SECONDARY AIR FILTER

[RE230985](#)

Replace annually and as required.



OIL FILTER (9360R)

[RE509672](#)

(9410R, 9460R, 9510R, 9560R)

[RE572785](#)

Initial oil change is 500 hours, then every 500 hours or annually, whichever occurs first. The extended 500 hour interval is only allowed if using PLUS-50™ II oil with a John Deere™ filter and diesel fuel with sulfur content less than 15mg/kg (15ppm). If all the conditions are not met, change oil and filter at 250 hours of operation.



PRIMARY & SECONDARY FUEL FILTER (9360R, 9410R, 9460R, 9510R, 9560R) IT4

[RE539465](#)

[DZ112918](#)



PRIMARY & SECONDARY FUEL FILTER TIER 2, (9410R, 9460R, 9510R, 9560R)

[RE532952](#)

[DZ112918](#)

Replace after every 500 hours or as indicated, whichever comes first.



FUEL WATER SEPARATOR FILTER (IF EQUIPPED)

[N378886](#)

Change after every 500 hours.



CAB



RECIRCULATION AIR FILTER

[RE291412](#)
[RE333569](#) CARBON

Replace after every 1000 hours or annually, whichever occurs first.



FRESH AIR FILTER

[RE284091](#)
[RE333567](#) CARBON

Replace after every 1000 hours or annually, whichever occurs first.

ENGINE



FUEL TANK VENT FILTER

[H216169](#) (2)

Replace after 1500 hours or 1 year, whichever occurs first.

HYDRAULICS



HYDRAULIC OIL FILTER

[RE577612](#)
QTY-2 (SINGLE REDUCTION AXLE)
QTY-3 (DOUBLE REDUCTION AXLE)

Replace every 1500 hours, or as required.

TRANSMISSION



[RE174130](#) MST
[RE577612](#) PST

Replace every 1500 hours.



JOHN DEERE

Genuine Parts and Service

For company use. RX532592

Apr 2022. Release Date.

CLICK PART NUMBER TO BUY

*See operator's manual for additional details.

CAPACITIES

9R Interim Tier 4 (IT4) Series Wheel Tractors(000101-014999) – 9360R, 9410R, 9460R, 9510R and 9560R

CAPACITIES (Approximate):

Fuel Tank

..... 1325 L (350 gal)

Cooling System Including Overflow Tank:

Cool-Gard™ II

9360R..... 42 L (11.1 gal)

9410R, 9460R, 9510R, 9560R 55 L (14.6 gal)

Crankcase including Filter:

Plus-50™ II

9360R..... 34 L (9.0 gal)

9410R, 9460R, 9510R, 9560R 48 L (12.7 gal)

24-Speed Transmission/Hydraulic Reservoir/SR Axles:

Hy-Gard™

9360R, 9410R, 9460R

Standard Flow 255.6 L (67.5 gal)

High Flow 259.4 L (68.5 gal)

Hydraulic Reservoir:

Hy-Gard™

Full - Hot..... 124.2 L (32.8 gal)

Full - Cold 101.9 L (26.9 gal)

Powershift Transmission/Hydraulic Reservoir:

Hy-Gard™

9360R, 9410R, 9460R – SR Axles

Standard Flow 282.1 L (74.5 gal)

9360R, 9410R, 9460R – SR Axles

High Flow 285.9 L (75.5 gal)

9510R, 9560R – DR Axles

Standard Flow 217.7 L (57.5 gal)












9510R, 9560R – DR Axles

High Flow 229.1 L (60.5 gal)

REPAIR PARTS GUIDE

















9R Interim Tier 4 (IT4) Series Wheel Tractors(000101-014999) – 9360R, 9410R, 9460R, 9510R and 9560R

ENGINE

	TORSIONAL DAMPER RE586976 - (9360R) RE584547 - (9410R,9460R,9460R,9510R,9560R)	1
	COMPRESSOR RE326205	2
	AUX DRIVE BELT R536677 -IT4 R533664 -T2 R329631 -(9360R)	3
	FAN DRIVE BELT R307304 -13.5 L Engine R568198 - 9.0 L Engine	4
	RADITOR CAP RE312969	5
	ENGINE BLOCK HEATER RE15940 - 220 V RE541654 - 120 V RE42139 - (9360R)	6
	WATER PUMP DZ102107 - (9360R) RE549117 - T2 DZ106318 - IT4	7
	BELT TENSIONER AN208610 - 13.5 L Engine T2 Fan Drive RE243154 - (9360R) DZ10469 - (9410R,9460R,9460R, 9510R,9560R) T2, AUX	8
	ALTERNATOR RE555751	9
	STARTER RE539584 - (9410R,9460R,9460R,9510R,9560R) RE549229 - (9360R)	10
	FUEL INJECTION PUMP DZ124926 - (9410R,9460R,9460R,9510R,9560R) RE543262 - (9360R)	11



CAB

	WIPER BLADE AL153661 Front And Rear	12
	INTERNAL REAR VIEW MIRROR AT186760	13
	EXTERNAL REAR VIEW MIRROR RE322784 - LH RE307815 - RH	14
	TECHNOLOGY MOUNTING SOLUTION RE317435 - Accessory Mounting BRE10015 - Cell Point Mounting BRE10255 - Tablet Mounting	14
	GAS CYLINDERS RE261886 - Rear Window RE234992 - LH, Door	15
HITCH AND SCV		
	HITCH MAINTENANCE R309355 - Sway Block, RH	16
	R304695 - Sway Block War Plate, RH	
	R309356 - Sway Block, LH	
	R304694 - Sway Block War Plate, LH	
	RE334232 - Hitch Position Sensor	
	SCV RE577560 - Breakway Coupler	17
	R186598 - Snap Ring	
	RE186600 - Seal Kit	
	RE293262 - Power Beyond Coupler	
	LIFT LINK PINS RE333939 - PIN R106409 - Draft Link Ball Stud	18
ENGINE		
	BATTERY TY25879B	19