

REPLACEMENT PARTS GUIDE

4049R Compact Utility Tractor (1LV4049RHHJ500001-) (Europe Edition)

ENGINE



ENGINE OIL
[TY26668](#) (10W-30 PLUS-50™ II) (5.4 L (1.4 gal))

Change Every 200 Hrs or Annually, whichever comes first.



FUEL FILTER

[MIU800645](#)

Change after every 400 Hrs/Annually.



AIR FILTER

[RE68048](#) (PRIMARY)

[RE68049](#) (SECONDARY)

Change every 600 hrs. or annually.



JD MULTI PURPOSE HD LITHIUM COMPLEX GREASE

[TY6341](#)

GREASE GUN

[TY26183](#)

Change As Required.



OIL FILTER

[M806419](#)

Change Every 200 Hrs or Annually, whichever comes first.



FUEL-WATER SEPARATOR

[AM881823](#) (SEPARATOR)

[M811032](#) (FILTER ELEMENT)

Change after every 400 Hrs. or annually.



HOME MAINTENANCE KIT

[LVA21039](#)

AXLE



FRONT AXLE OIL

[TY22000](#) (John Deere Low Viscosity Hy-Gard™)

Change every 50/400/600 Hrs.



TIE ROD

[LVA14951](#) (ASSEMBLY)

[LVA14960](#) (LH)

[LVA14959](#) (RH)



ELECTRICAL

KEY
[RE183935](#)

ROTARY SWITCH
[LVA21501](#)

BATTERY
[TY26442B](#) (12 V)

LED WORK LIGHT
[AM143579](#) (OOS) (12 V)

HEADLIGHT
[R136239](#) (12V 60/55 W)

FUEL & AIR
FILLER CAP
[AL213202](#)

CAB
CAB FILTER
[MIU10010](#)
 Clean or replace after every 50 hours and as Required.

RECIRCULATION AIR FILTER
[MIU10011](#)
 Clean or replace after every 50 hours and as required.

TRANSMISSION/ HYDRAULIC
TRANSMISSION/HYDRAULIC OIL
[TY22000](#) (John Deere Low Viscosity Hy-Gard™ - 5.5 L (1.5 gal))
 Change Every 1200 hours or 3 Years.

OIL FILTER
[RE45864](#) (TRANSMISSION)
[LVA10419](#) (HYDRAULIC)
 Change after every 400 Hrs. or Annually.

V - BELT
[LUVU29376](#) (LGTH = 1112 mm, WIDTH = 13.4 mm, TK = 9.6 mm)