

# REPLACEMENT PARTS GUIDE

948L-II Skidder (PIN: 1DW948L\_\_ \_F690814— )



## HYDRAULIC RESERVOIR BREATHER FILTER

[AT421408](#)

Interval (hrs) - 4000.



## HYDRAULIC SYSTEM OIL FILTER ELEMENT

[F061786](#)

Interval (hrs) - 4000.



## CAB RECIRCULATING AIR FILTER ELEMENT

[AT307501](#)

Interval (hrs) - As Required.



## CAB FRESH AIR FILTER ELEMENT

[AT191102](#)

Interval (hrs) - As Required.



## PRIMARY FUEL FILTER (9.0 L ENGINES)

[RE539465](#)

Interval (hrs) - 500.



## AUXILIARY FUEL FILTER ELEMENT (9.0 L ENGINES ONLY)

[AT365869](#)

Interval (hrs) - 500.



## FINAL FUEL FILTER (9.0 L ENGINES)

[RE533910](#)

Interval (hrs) - 500.



## DIESEL PARTICULATE FILTER (COMPONENT OF EXHAUST FILTER)

[RE559541](#)

Interval (hrs) - As Required.



## AXLE OIL FILTER ELEMENTS

[AT367635](#)

Interval (hrs) - 1000.



## OPEN CRANKCASE VENTILATION (OCV) FILTER (640L-II AND 648L-II)

[RE540710](#)

Interval (hrs) - 1500.



## OPEN CRANKCASE VENTILATION (OCV) FILTER (748L-II)

[RE553703](#)

Interval (hrs) - 1500.



## ENGINE OIL FILTER (6.8 L ENGINES)

[RE539279](#)

Interval (hrs) - 500.



## AUXILIARY FUEL FILTER ELEMENT (6.8 L ENGINE ONLY)

[AT365870](#)

Interval (hrs) - 500.



## PRIMARY AND FINAL FUEL FILTER KIT (6.8 L ENGINES)

[RE556406](#)

Interval (hrs) - 500.



**JOHN DEERE**  
Genuine Parts and Service

# REPLACEMENT PARTS GUIDE

## 948L-II Skidder (PIN: 1DW948L\_\_ \_F690814— )



### ENGINE ROCKER ARM COVER GASKET (6.8 L ENGINES)

[R528743](#)

Interval (hrs) - 2000.

### DUST UNLOADER VALVE

[T158495](#)

Interval (hrs) - As Required.

### SECONDARY AIR FILTER (6.8 L ENGINES ONLY)

[AT175224](#)

Interval (hrs) - As Required.

### DIESEL EXHAUST FLUID (DEF) HEADER SUCTION FILTER AND BAFFLE

[AT484544](#)

Interval (hrs) - 4000.

### DIESEL EXHAUST FLUID (DEF) TANK BREATHER FILTER

[H216169](#)

Interval (hrs) - 4000.

### DIESEL EXHAUST FLUID (DEF) DOSING UNIT FILTER

[RE554498](#)

Interval (hrs) - 4000.

### ENGINE DRIVE SHAFT (748L, 848L, AND 948L ONLY)

[AT440739](#)

Interval (hrs) - 10000.

### ENGINE ROCKER ARM COVER GASKET (9.0 L ENGINES)

[R526607](#)

Interval (hrs) - 2000.

### SECONDARY TRANSMISSION OIL FILTER

[T436566](#)

Interval (hrs) - 4000.

### PRIMARY TRANSMISSION OIL FILTER

[AT468647](#)

Interval (hrs) - 2000.

### ENGINE OIL FILTER ELEMENT (9.0 L ENGINES ONLY)

[DZ101884](#)

Interval (hrs) - 500.

### ENGINE DRIVE SHAFT (640L AND 648L ONLY)

[AT440747](#)

Interval (hrs) - 10000.

### PRIMARY AIR FILTER (6.8 L ENGINES ONLY)

[AT223226](#)

Interval (hrs) - As Required.

### DIESEL EXHAUST FLUID (DEF) TANK BREATHER FILTER












[H216169](#)

Interval (hrs) - 2000.



# OILS AND CAPACITIES INFORMATION

## 948L-II Skidder (PIN: 1DW948L\_\_F690814— )

Part Description	Part Number	Qty or capacity	Change Interval In Hours
John Deere Plus-50™ II Engine Oil <sup>3</sup> 	<a href="#">TY26669</a>	28.5 L (7.5 gal)	500
John Deere Hy-Gard™ Oil3: Front Axle Oil—1400 Series 	<a href="#">TY6354</a>	31.0 L (8.2 gal)	2000
John Deere Hy-Gard™ Oil3: Rear Axle Oil—1400 Series 	<a href="#">TY6354</a>	32.0 L (8.5 gal)	2000
John Deere Hy-Gard™ Oil3: Front Axle Oil—SWEDA 	<a href="#">TY6354</a>	31.4 L (8.3 gal)	2000
John Deere Hy-Gard™ Oil3: Rear Axle Oil—SWEDA 	<a href="#">TY6354</a>	32.4 L (8.6 gal)	2000
John Deere Hy-Gard™ Oil3: Front Axle Oil—1700 Series 	<a href="#">TY6354</a>	106.0 L (28.0 gal)	2000
John Deere Hy-Gard™ Oil3: Rear Axle Oil—1700 Series 	<a href="#">TY6354</a>	107.0 L (28.3 gal)	2000
John Deere Hy-Gard™ Oil3: Park Brake Oil 	<a href="#">TY6354</a>	0.8 L (27.0 floz)	1000
John Deere Hy-Gard™ Oil3: Transmission Oil 	<a href="#">TY6354</a>	57.0 L (15.1 gal)	2000
John Deere Hydrau™ Oil3: Hydraulic System 	<a href="#">TY27367</a>	123.6 L (32.7 gal)	4000
John Deere Hydrau™ Oil3: Winch Oil—4000 Series (if equipped) 	<a href="#">TY27367</a>	35.2 L (9.3 gal)	4000
John Deere Hydrau™ Oil3: Winch Oil—6000 Series (if equipped) 	<a href="#">TY27367</a>	45.5 L (12.0 gal)	4000
John Deere Cool-Gard™ II Premix (6.8 L engines) 	<a href="#">TY26575</a>	36.4 L (9.6 gal)	6000
John Deere Cool-Gard™ II Premix (9.0 L engines) 	<a href="#">TY26575</a>	41.7 L (11.0 gal)	6000

# OILS AND CAPACITIES INFORMATION

## 948L-II Skidder (PIN: 1DW948L\_\_F690814— )

Part Description	Part Number	Qty or capacity	Change Interval In Hours
<b>Fluid Analysis Test Kits<sup>4</sup></b>			
Diesel Engine Oil	<a href="#">AT346594</a>	1	250
Transmission Oil	<a href="#">AT346594</a>	1	500
Hydraulic Oil	<a href="#">AT346594</a>	1	500
Axle Oil	<a href="#">AT346594</a>	2	500
Park Brake Oil	<a href="#">AT346594</a>	1	500
Diesel Fuel	<a href="#">TY27329</a>	1	500
Winch Gear Case Oil (if equipped)	<a href="#">AR69444</a>	1	500
Engine Coolant	<a href="#">TY27787</a>	1	500
<sup>3</sup> See operator's manual for recommended oil type and oil viscosities based on operating temperatures. <sup>4</sup> Based on fluid analysis results, intervals may need to be adjusted for operating conditions. Consult an authorized John Deere dealer.			

*Plus-50 is a trademark of Deere & Company*  
*Hydrau is a trademark of Deere & Company*  
*Hy-Gard is a trademark of Deere & Company*  
*Cool-Gard is a trademark of Deere & Company*



**CLICK PART NUMBER TO BUY**

\*See operator's manual for additional details.

## Service Intervals

As Required	
<input type="checkbox"/> Clean cooler cores	<input type="checkbox"/> Fill and charge pressurized water system (if equipped)
<input type="checkbox"/> Inspect accessory drive belt	<input type="checkbox"/> Check fire extinguisher charge
<input type="checkbox"/> Replace engine air cleaner elements	<input type="checkbox"/> Lubricate cab door hinges
<input type="checkbox"/> Check tire pressure	<input type="checkbox"/> Check cab recirculating air filter
<input type="checkbox"/> Check wheel bolt torque	<input type="checkbox"/> Check cab fresh air filter
<input type="checkbox"/> Clean fuel tank inlet screen	<input type="checkbox"/> Service exhaust filter
Every 10 Hours or Daily	
<input type="checkbox"/> Check engine coolant level	<input type="checkbox"/> Clean engine air intake precleaner screen
<input type="checkbox"/> Check engine oil level	<input type="checkbox"/> Check and clean engine air intake precleaner dust unloader valve
<input type="checkbox"/> Check transmission oil level	<input type="checkbox"/> Lubricate articulation points
<input type="checkbox"/> Check hydraulic system oil level	<input type="checkbox"/> Lubricate yoke and cross head (grapple skidders only)
<input type="checkbox"/> Check diesel exhaust fluid (DEF) level	<input type="checkbox"/> Lubricate tong linkage and cylinder pivots (grapple skidders only)
<input type="checkbox"/> Check and drain primary fuel filter and water separator	<input type="checkbox"/> Lubricate arch/boom linkage and cylinder pivots (grapple skidders only)
<input type="checkbox"/> Check and drain auxiliary fuel filter and water separator	<input type="checkbox"/> Lubricate winch fairlead rollers (cable skidders only)
Every 100 Hours	
<input type="checkbox"/> Lubricate rear axle pinion seal and park brake seals	<input type="checkbox"/> Lubricate blade and cylinder pivots
<input type="checkbox"/> Lubricate front axle pivots, pinion seal, and hydraulic steering cylinder pins	<input type="checkbox"/> Lubricate winch fairlead rollers (if equipped, grapple skidders only)
Every 250 Hours	
<input type="checkbox"/> Take engine oil sample	
Initial Service—500 Hours	
<input type="checkbox"/> Drain and refill axle oil	<input type="checkbox"/> Replace axle oil filters
Every 500 Hours	
<input type="checkbox"/> Drain and refill engine oil and replace filter	<input type="checkbox"/> Check engine air intake hoses
<input type="checkbox"/> Replace primary fuel filter and water separator	<input type="checkbox"/> Take transmission oil sample
<input type="checkbox"/> Replace auxiliary fuel filter and water separator	<input type="checkbox"/> Take hydraulic oil sample
<input type="checkbox"/> Replace final fuel filter	<input type="checkbox"/> Take axle oil sample
<input type="checkbox"/> Check axle oil level	<input type="checkbox"/> Take park brake oil sample
<input type="checkbox"/> Check park brake oil level	<input type="checkbox"/> Take engine coolant sample
<input type="checkbox"/> Lubricate front, rear, and articulation drive shafts	<input type="checkbox"/> Take diesel fuel sample
<input type="checkbox"/> Adjust grapple damper (grapple skidders only)	<input type="checkbox"/> Take winch gear case oil sample (if equipped)
<input type="checkbox"/> Check open crankcase ventilation (OCV) system	
Every 1000 Hours	
<input type="checkbox"/> Drain and refill park brake oil	<input type="checkbox"/> Lubricate grapple rotate bearing (grapple skidders only)
<input type="checkbox"/> Replace axle oil filters	<input type="checkbox"/> Check coolant condition
Every 1500 Hours	
<input type="checkbox"/> Replace open crankcase ventilation (OCV) filter (640L-II, 648L-II, and 748L-II only)	

## Service Intervals

Initial Service—2000 Hours	
<input type="checkbox"/> Replace hydraulic system oil filter	
Every 2000 Hours	
<input type="checkbox"/> Drain and refill transmission oil and replace primary transmission oil filter	<input type="checkbox"/> Check and adjust engine valve lash
<input type="checkbox"/> Drain and refill axle oil	<input type="checkbox"/> Inspect sun gear (1700 series axles equipped with large duals only)
<input type="checkbox"/> Replace fuel tank breather	
Every 4000 Hours	
<input type="checkbox"/> Drain and refill hydraulic system oil	<input type="checkbox"/> Replace diesel exhaust fluid (DEF) dosing unit filter
<input type="checkbox"/> Replace hydraulic system oil filter	<input type="checkbox"/> Replace diesel exhaust fluid (DEF) tank breather filter
<input type="checkbox"/> Replace hydraulic reservoir breather filter	<input type="checkbox"/> Clean diesel exhaust fluid (DEF) tank
<input type="checkbox"/> Drain and refill winch oil (if equipped)	<input type="checkbox"/> Replace diesel exhaust fluid (DEF) header suction filter and baffle
<input type="checkbox"/> Replace secondary transmission oil filter	
Every 6000 Hours	
<input type="checkbox"/> Drain and refill engine cooling system	
Every 10 000 Hours	
<input type="checkbox"/> Replace engine drive shaft	