

REPLACEMENT PARTS GUIDE

5EF Series Tractor - 5075EF (South American Edition)

ENGINE



PRIMARY FUEL FILTER [RE62418](#)

Replace after every 250 hours and annually.



OIL FILTER [RE507204](#) (FOR INDIA ONLY) [T19044](#) (FOR EXPORT)

Replace initially after 100 hours and every 375 hours and annually.

ENGINE



PRIMARY AIR FILTER

[RE282286](#)



SECONDARY AIR FILTER [RE282287](#)

Replace after cleaning 6 times or annually which ever occurs first.

TRANSMISSION



HYDRAULIC OIL FILTER [RE45864](#)

Replace initially after 100 hours and 1500 hours.



JOHN DEERE
Genuine Parts and Service

CAPACITIES

5EF Series Tractor - 5075EF (South American Edition)

CAPACITIES (Approximate):

Fuel Tank:

..... 70 L (18.5 gal)

Cooling System:

Cool-Gard™ II

..... 11 L (2.9 gal)

Hy-Gard™

..... 40 L (10.57 gal)

Transmission and Hydraulic System:

REPLACEMENT PARTS GUIDE

5EF Series Tractor - 5075EF (South American Edition)

ENGINE



BRAKE DISK

[SJ17870](#) (REAR WHEEL)

[L77358](#) (ACTUATING DISK)

[RE45938](#) (MFWD)



CLUTCH DISK

[RE227648](#) (PTO)

[SJ25811](#) (TRACTION)



BATTERY

[SJ10989](#)



ALTERNATOR

[RE234714](#)



FAN BELT DRIVE

[R216949](#) (FAN ASSEMBLY)
(LGTH = 1360 mm)



CAB



SEAT

[SJ17647](#) (ASSEMBLY)

AXLE



TIE ROD

[RE61835](#) (ASSEMBLY)

[RE61836](#) (RH)

[RE61833](#) (LH)



JOHN DEERE
Genuine Parts and Service