

# REPLACEMENT PARTS GUIDE

## 5E series Stage IIIB and Stage V - 5050E, 5058E, 5067E and 5075E Tractors

### ENGINE



#### OIL FILTER

[RE519626](#) - (5050E)  
[RE519626](#) - (5058E, 5067E, 5075E)  
(031583)  
[DZ114256](#) - (5050E)

Replace after first 100 hours then change every 375 hours, every 500 hours.



#### PRIMARY AIR FILTER

[SU29300](#)

#### SECONDARY AIR FILTER

[SU29301](#)

Change after every 250 hours or annually which



#### FUEL FILTER

[RE67225](#) - (5050E)  
[R536698](#) - (5075E, 5058E, 5067E) -  
[DZ114096](#)

Replace every 250 hours, every 500 hours



#### CRANKCASE VENT FILTER

(5075E, 5058E, 5067E) - [RE553871](#)

Clean every 600 hours and Replace as required.



### CAB



#### RECIRCULATION AIR FILTER

[RE195491](#)

Change annually or as required.  
(if equipped).



#### FRESH AIR FILTER

[RE198488](#)

Clean every 600 hours, annually, and as required per conditions (if equipped)

### HYDRAULIC



#### OIL FILTER

[RE45864](#)

Replace after first 100 hours then every 500 hours and every 1200 hours.



**JOHN DEERE**  
Genuine Parts and Service

# CAPACITIES

## 5E series Stage IIIB and Stage V - 5050E, 5058E, 5067E and 5075E Tractors

### CAPACITIES (Approximate):

#### Fuel Tank:

..... 82 L (21.6 gal)

#### Cooling System:

##### Cool-Gard™ II

5075M, 5058E, 5067E (Cab)..... 12.5 L (2.74 gal)

OOS..... 9 L (1.97 gal)

#### Crankcase with Filter:

##### Plus-50™ II

5075M..... 8.5 L (2.2 gal)

#### Transmission and Hydraulic System:

##### Hy-Gard™

SyncShuttle™ (9X3)..... 38 L (8.35 gal)

[Return to Filter Overview](#)

#### PowrReverser™

(12X12) 5058E, 5067E, 5075E..... 43 L (9.45 gal)

(24X12) 5058E, 5067E, 5075E..... 45.5 L (10 gal)

#### Mechanical Front Wheel Drive (MFWD) Axle Housing:

##### MFWD Differential Housing

..... 4.5 L (0.98 gal)

#### Mechanical Front Wheel Drive (MFWD) Hubs (Each):

##### Hy-Gard™

..... 0.7 L (0.15 gal)

[Return to Filter Overview](#)

# REPLACEMENT PARTS GUIDE


## 5E series Stage IIIB and Stage V - 5050E, 5058E, 5067E and 5075E Tractors

### ENGINE



#### BRAKE DISK

[SJ40143](#)  
[RE45938](#) (MFWD Differential, W/O Seals)



#### CLUTCH DISK

[SJ29351](#) (Traction)(5050E, 5058E, 5067E)  
[RE242274](#) (PTO Clutch Disk)(5050E, 5058E, 5067E)  
[SJ10903](#) (5075E)



#### BATTERY

[TY24394B](#) (WET CHARGED BATTERY) (5055E)  
[MCYP700PF](#) (ALL)



#### ALTERNATOR

[SJ14155](#) (Cab)(110A)(5050E)  
[SJ27434](#) (Cab)(110A)(5058E, 5067E, 5075E)  
[SJ30896](#) (OOS)(50A)(5050E, 5075E)  
[SJ27432](#) (OOS)(70A)(5058E, 5067E, 5075E)



#### FAN BELT DRIVE

[R73784](#) (OOS)(5050E)  
[SU26138](#) (Cab)(5050E)  
[SU28901](#) (Air Conditioner)(5058E, 5067E, 5075E)  
[SU28900](#) (Fan And Alternator)(5058E, 5067E, 5075E)  
[SU39383](#) (Without Air Conditioner) (5058E, 5067E, 5075E)



### CAB



#### SEAT

[SJ31217](#) (W/ Air Suspension)  
[SJ29653](#) (OOS)(Back)(5058E, 5067E, 5075E)  
[SJ29652](#) (OOS)(Bottom)(5058E, 5067E, 5075E)  
[SJ17236](#) (Stage 3A)(5050E, 5075E)  
[RE258487](#) (Bottom)(Stage 3A)(5050E, 5075E)  
[RE258488](#) (Back)(Stage 3A)(5050E, 5075E)  
[LG102452](#) (Instructional Seat)  
[AL173179](#) (Bottom) AL207601(Back)  
[SJ27853](#) (W/ Mechanical Suspension) (5050E, 5058E, 5067E)

### AXLE



#### TIE ROD

[RE271437](#) (Front Axle, MFWD, W/O Seals)  
[RE271440](#) (Ball Joint)  
[RE271441](#) (90 Degree)  
[SJ31115](#) (W/O Seals, MFWD)  
[SJ32922](#) (Tie rod End)  
[SJ32923](#) (9 Ball Joint)



**JOHN DEERE**  
 Genuine Parts and Service

[CLICK PART NUMBER TO BUY](#)

\*See operator's manual for additional details.