

REPLACEMENT PARTS GUIDE

6B Series - 954 (-511910), 1104, 1204 (-511431), 1354 (-510197), 1404 Tractors



CAB

RECIRCULATION AIR FILTER
[RE195491](#) (1204)
[SU41628](#)
[SU41769](#)

Clean after every 250 hours and annually. change as required.

FRESH AIR FILTER
[RE198488](#)

Service after every 250 hours. change as required.

HYDRAULIC

OIL FILTER
[SJ11792](#)

Replace after first 100 hours then after every 500 hours.
(Click here for [capacity](#))

ENGINE

WATER SEPARATOR
[N378886](#) (1104, 1204, 1354)

Replace after every 500 hours.

ENGINE

OIL FILTER
[RE504836](#)

Replace after Initial 100 Hours and every 250 hours.
(Click here for [capacity](#))

PRIMARY FUEL FILTER
[RE546336](#) (954, 1104, 1204, 1354)
[RE541922](#) (1404)
[RE522868](#) (- 008103) (954)
[RE509208](#) (008104 -) (954)

FINAL FUEL FILTER
[RE526657](#), [RE544394](#)
(954, 1104, 1204, 1354)
[RE5441925](#) (1404)

PRIMARY AIR FILTER
[AL172780](#)
[SU29684](#) (954)

SECONDARY AIR FILTER
[AL150288](#) (954, 1204, 1354)
[SU29685](#) (954)

Replace after every 1000 hours or annually whichever occurs first. Change as required.



CAPACITIES

6B Series - 954 (-511910), 1104, 1204 (-511431), 1354 (-510197), 1404 Tractors



CAPACITIES (Approximate):

Fuel Tank:

954.....	150 L (39.62 gal)
1104, 1204, 1354.....	210 L (55.48 gal)
1404 (Four Cylinders).....	210 L (55.48 gal)
1404 (Six Cylinders).....	255 L (67.36 gal)

Crankcase including Filter Change:

Plus-50™ II

954, 1104, 1204, 1354 (Deere Engine).....	15 L (3.96 gal)
954, 1104, 1204, 1354 (Supplier Engine).....	17 L (4.49 gal)
1404 (Four Cylinders).....	17 L (4.49 gal)
1404 (Six Cylinders).....	21.1 L (6.1 gal)

Cooling System:

Cool-Gard™ II

954.....	18 L (4.76 gal)
1104, 1204, 1354 (Deere Engine).....	18 L (4.76 gal)
1104, 1204, 1354 (Supplier Engine).....	20 L (5.28 gal)
1404 (Four Cylinders).....	18 L (4.76 gal)
1404 (Six Cylinders).....	23 L (6.08 gal)

Transmission and Hydraulic System:

Hy-Gard™

.....	60 L (15.65 gal)
-------	------------------

Mechanical Front Wheel Drive (MFWD) Axle Housing: Hy-Gard™

954, 1104.....	5.5 L (1.45 gal)
1204, 1354 (Deere Engine).....	5 L (1.32 gal)
1204, 1354 (Supplier Engine).....	5.5 L (1.45 gal)
1404.....	5 L (1.32 gal)

Mechanical Front Wheel Drive (MFWD) Hubs (Each): Hy-Gard™

954, 1104.....	1.1 L (0.29gal)
1204, 1354 (Deere Engine).....	0.8 L (0.21 gal)
1204, 1354 (Supplier Engine).....	1.1 L (0.29gal)
1404.....	0.8 L (0.21 gal)

[Return to Filter Overview](#)

REPLACEMENT PARTS GUIDE

6B Series - 954 (-511910), 1104, 1204 (-511431), 1354 (-510197), 1404 Tractors



ENGINE

BRAKE DISK



[SU34458](#) (ALL) (Hand Brakes)
[NF501851](#) (1140,1240) (MFWD)

CLUTCH DISK



[SU52537](#) (1404)
[YZ91139](#) (954,1104,1204,1354)

BATTERY



[SJ19484](#) (1204,1354)
[SJ36671](#) (954) (95 HP Engine)

ALTERNATOR



[SJ24309](#) (90A) (ALL)



CAB

SEAT



[SJ31407](#) (1204,1404) (Without Arm rest)
(Optional)

[SJ31428](#) (1204,1404)
(Bottom) (With outArm rest) (Optional)

[SJ31429](#) (1204,1404) (Without Arm rest)
(Back) (With outArm rest) (Optional)

[SJ29370](#) (954,1204,1354) (Bottom)

[SJ29371](#) (954,1204,1354) (Back)

[SJ20422](#) (With Arm rest) (All)

[SJ20423](#) (With Out Arm rest) (All)

[SJ29370](#) (Bottom)

[SJ29371](#) (Back)

FAN DRIVE BELT



[L153280](#) (954,1204,1354,1404)
(95 HP, With out AC)

[L111600](#) (954,1204,1354,1404)
(95 HP, With AC)

[L111601](#) (954,1104) (90 HP, With AC)

[L114488](#) (954,1104) (90 HP, Without AC)

[L114293](#) (954) (With AC)

[L114290](#) (954) (Without AC, With AirPump)

AXLE

TIE ROD



[AL204774](#) (1204,1354,1404) (MFWD,Basic)

[AL226443](#) (1204) (MFWD,LitePaddy)

[AL225626](#) (1104,1204) (MFWD,Lite Dry)

[AL227349](#) (954)