

# REPLACEMENT PARTS GUIDE

## 6E Series - 6100E, 6110E, 6115E, 6125E and 6130E Tractors

### ENGINE



#### PRIMARY FUEL FILTER

[RE541922](#)

#### SECONDARY FUEL FILTER

[RE526557](#) (6100E, 6115E, 6130E)

[RE522868](#) (6100E, 6110E, 6125E)

Replace after every 500 hours.



#### PRIMARY AIR FILTER

[SU20768](#)

#### SECONDARY AIR FILTER

[RE253519](#)

Replace after every 1000 hours or annually, whichever comes first.

#### OIL FILTER

[RE504836](#)

Replace at 100 hours then every 500 hours or annually, whichever occurs first.



### CAB



#### RECIRCULATION AIR FILTER

[RE195491](#)

Clean after every 250 hours and annually. (change as required)



#### FRESH AIR FILTER

[RE198488](#)

Clean after every 25 hours and annually. (change as required)

### HYDRAULIC



#### OIL FILTER

[SJ11792](#)

Replace after first 100 hours then after 500 hours or after 1000 hours or annually.



**JOHN DEERE**  
Genuine Parts and Service

# CAPACITIES

## 6E Series - 6100E, 6110E, 6115E, 6125E and 6130E Tractors

### CAPACITIES (Approximate):

#### Fuel Tank:

..... 158 L (41.7 gal)

#### Cooling System:

##### Cool-Gard™II Premix

6105D, 6115D..... 17.7 L (4.7 gal)

6130D, 6140D..... 18.7 L (4.9 gal)

#### Crankcase with Filter:

##### Plus-50™II

..... 15 L (4 gal)

#### Transmission Case:

##### Hy-Gard™II

..... 58 L (15.3 gal)

#### MFWD Axle Housing:

##### GL-5

..... 5 L (1.32 gal)

#### MFWD Wheel Hub (Each Side):

##### GL-5

..... 0.8 L (0.21 gal)

# REPLACEMENT PARTS GUIDE

## 6E Series - 6100E, 6110E, 6115E, 6125E and 6130E Tractors

### ENGINE



#### BRAKE DISK

[AL160176](#) (MFWD)  
[SU34458](#) (HANDBRAKE)



#### BATTERY

[TY25879](#) (DRY CHARGED BATTERY)  
(6100E, 6110E, 6125E)  
[TY6128](#) (12 V)



#### ALTERNATOR

[RE544809](#) (90A)



#### FAN BELT DRIVE

[DZ119970](#) (OOS)(6100E, 6115E, 6130E)  
[DZ118886](#) (CAB)(6100E, 6115E, 6130E)  
[T428834](#) (CAB)(6110E, 6125E)  
[DZ119521](#) (RADIATOR FAN)(OOS)(6100E,  
6110E, 6125E)



### CAB



#### SEAT

[RE276007](#) (W/ MECHANICAL  
SUSPENSION, OOS)  
[TCA18457](#) (BACK)  
[TCA18456](#) (BOTTOM)  
[SJ12046](#) (WITH SWITCH)  
[RE251272](#) (MECHANICAL SUSPENSION,  
CAB)  
[AL116984](#) (BACK)  
[SJ292621](#) (BOTTOM)  
[RE276006](#) (AIR SUSPENSION, CAB)  
[RE250427](#) (INSTRUCTIONAL SEAT)  
[AL173179](#) (BOTTOM)  
[AL207601](#) (BACK)

### AXLE



#### TIE ROD

[AL150098](#) (OOS)(6100E, 6115E, 6130E)  
[AL204774](#) (MFWD)(USE WITH AL221102)  
[AL204777](#) (BALL JOINT)  
[AL231184](#) (TIE ROD END)  
[AL231187](#) (MFWD)(USE WITH AL221102)  
[AL231185](#) (BALL JOINT)



**JOHN DEERE**  
Genuine Parts and Service