

# REPLACEMENT PARTS GUIDE

## 7000 Series - 7500 Tractor



### CAB

#### RECIRCULATION AIR FILTER

[AL225552](#) (AIR FILTER)

Clean for every 1250Hrs



### HYDRAULIC

[RE45864](#) (FILTER ELEMENT)  
[RE205726](#) (HYDRAULIC OIL FILTER)

Replace the filters for every 100 Hrs



### ENGINE

#### OIL FILTER

[T19044](#) (OIL FILTER)  
[CQ29104](#) (FILTER)  
[AL221066](#) (TRANSMISSION OIL FILTER)

Replace for every 750Hrs



#### AIR FILTER

[DQ28600](#)  
[SJ17530](#) (FILTER ELEMENT)  
[DQ04466](#) (FILTER ELEMENT)

Clean for every 1250Hrs



#### PRIMARY FUEL FILTER

[RE62419](#) (FILTER ELEMENT)  
[DQ24057](#) (PRE-FILTER)  
[DQ72611](#)

Clean for every 1250Hrs



# REPLACEMENT PARTS GUIDE

## 7000 Series - 7500 Tractor

**CAPACITIES (Approximate):**

Fuel Tank:

Open Operator Station ..... 307 L (81 gal)

Cooling System:

Cool-Gard™ II

Open Operator Station ..... 19 L ( 5 gal)

Transmission and Hydraulic System:

Hy-Gard™

7500.....64 L (17 gal)

Mechanical Front Wheel Drive (MFWD) Axle Housing:

Hy-Gard™

7500.....6.8 L (1.8 gal)

# REPLACEMENT PARTS GUIDE

## 7000 Series - 7500 Tractor



### ENGINE



#### BRAKE DISK

[RE186966](#)



#### CLUTCH DISK

[R95109](#) (PTO CLUTCH)  
[R95110](#) (PTO CLUTCH)  
[RE101165](#)



#### BATTERY

[DQ25557](#) (DRY CHARGED BATTERY)



#### ALTERNATOR

[AJ58541](#) (12V - 50A)  
[AJ58637](#)



### CAB



#### SEAT

[DQ34703](#)  
[DQ42169](#)  
[DQ34703](#)  
[DQ61889](#) (SUPER CONFORT SEAT WITH CAB)

### ENGINE



#### FAN DRIVE BELT

[CQ33577](#) (AIR COMPRESSOR)

### AXLE



#### TIE ROD

[RE54029](#) (TIE ROD ASSEMBLY)  
[DQ72729](#) (DRIVE CYLINDER ASSEMBLY)  
[DQ67136](#) (TIE ROD END)  
[AL119215](#) (AXLE CASING)  
[AL110918](#) (TIE ROD ASSEMBLY)



**JOHN DEERE**  
Genuine Parts and Service

CLICK PART NUMBER TO BUY

\*See operator's manual for additional details.